

Step 1:

Slide Greenskin (GS) over electrical box. Use fasteners to secure the GS to the back wall.



Step 2:

Slide building wrap under bottom of GS and bring up to the bottom of electrical box.



Step 3:

Overlap building wrap on top of GS and cut an opening around the closed cap of the GS.



Step 4:

Once exterior is finished, simply trim excess material from GS and remove temporary wall stiffener.

