

Step 1:

If necessary, to adjust the Pro-Flash (PF) size simply slit the appropriate tear ring in the rubber and pull to remove.



Step 2:

Slide PF over pipe penetration.



Step 3:

Slide building wrap under bottom of PF and bring up to the bottom of the pipe.



Step 4:

Overlap building wrap on top of PF and cut an opening around the pipe.

