

### **Step 1:**

If necessary, to adjust the Pro-Flash (PF) size simply slit the appropriate tear ring in the rubber and pull to remove.



### **Step 2:**

Slide PF over pipe penetration.



### **Step 3:**

Slide building wrap under bottom of PF and bring up to the bottom of the pipe.



### **Step 4:**

Overlap building wrap on top of PF and cut an opening around the pipe.

